

Eyepiece Instructions

CEP-1, CEP-1b, & NEP-80

Remove your Canon, Nikon, or Fuji camera's eyepiece.

Line up the AquaTech Eyepiece directly above the viewfinder. Ensure that the AquaTech Eyepiece slides into the groove on the camera's viewfinder, then push down firmly.



NEP-1 Eyepiece

Remove your Nikon camera's eyepiece by unscrewing from the viewfinder in a counter-clockwise direction.

Line the AquaTech Eyepiece threads with that of the camera's viewfinder. Install the AquaTech Eyepiece by screwing it down in a clockwise direction until it locks into place. You can then attach your Nikon eyepiece by screwing it into the AquaTech Eyepiece.

